

FIG. 1

DVD VOLUME SPACE





FIG. 2

VMG



005640 : 2982550

FIG. 3





FIG. 4

VOB



00940 : 03.03.00

FIG. 5




FIG. 6

100




FIG. 7

| |
|--|
| DVD_ID CORRESPONDING TO DVD INSERTED INTO DVD PLAYER |
| VTS NUMBER OF VTS CORRESPONDING TO TITLE BEING PLAYED |
| PLAYBACK TIME WHEN PLAYBACK START POSITION IS MARKED |

009240-2382500

FIG. 8




FIG. 9

| MARKED-PLAYBACK-START-POSITION SELECTION-MENU SCREEN | | |
|---|---|---|
| IMAGE CORRESPONDING TO MARKED PLAYBACK START POSITION A | IMAGE CORRESPONDING TO MARKED PLAYBACK START POSITION B | IMAGE CORRESPONDING TO MARKED PLAYBACK START POSITION C |
| IMAGE CORRESPONDING TO MARKED PLAYBACK START POSITION D | IMAGE CORRESPONDING TO MARKED PLAYBACK START POSITION E | IMAGE CORRESPONDING TO MARKED PLAYBACK START POSITION F |
| IMAGE CORRESPONDING TO MARKED PLAYBACK START POSITION G | IMAGE CORRESPONDING TO MARKED PLAYBACK START POSITION H | IMAGE CORRESPONDING TO MARKED PLAYBACK START POSITION I |

FIG. 10

| MARKED-PLAYBACK-START-POSITION SELECTION-MENU SCREEN | | |
|---|---|---|
| IMAGE CORRESPONDING TO MARKED PLAYBACK START POSITION A | IMAGE CORRESPONDING TO MARKED PLAYBACK START POSITION B | IMAGE CORRESPONDING TO MARKED PLAYBACK START POSITION C |
| IMAGE CORRESPONDING TO MARKED PLAYBACK START POSITION D | IMAGE CORRESPONDING TO MARKED PLAYBACK START POSITION E | IMAGE CORRESPONDING TO MARKED PLAYBACK START POSITION F |
| IMAGE CORRESPONDING TO MARKED PLAYBACK START POSITION G | IMAGE CORRESPONDING TO MARKED PLAYBACK START POSITION H | IMAGE CORRESPONDING TO MARKED PLAYBACK START POSITION I |


005240-2982560

FIG. 11

| |
|---|
| CREATION DATE OF DATA |
| DISK NAME OF DVD INSERTED INTO DVD PLAYER |
| VTS NUMBER OF VTS CORRESPONDING TO TITLE BEING PLAYED WHEN STOPPED |
| PTT NUMBER CORRESPONDING TO CHAPTER BEING PLAYED WHEN STOPPED |
| STOP POSITION TIME |

00920" 29925560

FIG. 12



00557869-0000

FIG. 13




FIG. 14

| STOP POSITION MENU SCREEN | | | | |
|---------------------------|-------------|----------------|------------------|-----------|
| (RECORD DATE) | (DISK NAME) | (TITLE NO.) | (CHAPTER NO.) | (COMMENT) |
| 990125 | oooooooooo | 2 | 3 | xxx |
| 990115 | xxx | 3 | 3 | xxx |
| 990115 | xxx | 3 | 5 | ddd |
| 990105 | dddddddddd | 2 | 2 | ooo |
| 990105 | oooooooooo | 1 | 7 | ooo |
| 990105 | □□□□□□ | 3 | 4 | ddd |
| ⋮ | | | | |